
FLATSCAN WITHOUT MOUNTING ACCESSORY
FLATSCAN WITH MOUNTING ACCESSORY
Minimum angular adjustment
Maximum angular adjustment
143.2
146.8
Detection zone
Dead zone
SECTION A-A
127.7
124
DETECTION FIELD
Ø 4.5
Area for free installation of the sensor if the three holes provided are unusable